WAAS Web Application Portal

Precision Approach (PA) Summary

Contents

erview of Precision Approach (PA) Summary	3
tes	6
sition Errors	8
V Coverage	14
V 200 Coverage	17
tal Area Covered	20
ert Explorer	22
CON	30
o Nav Messages	34
bSystem Alerts	35
/T6 Alerts	36
tch Events	37
ew Glitch Event Details	40
M Data	41
nge Errors	44

ono Errors	46
Data Outages	47
DEI Network	47
PRN138 L1SNR	49
PA Position Errors	50
dits	51
/iew UDREIs	53
/iew IGPs By Region and Max KP Index	55


Overview of Precision Approach (PA) Summary

As part of the William J. Hughes Technical Center WAAS Test Team website (<u>www.nstb.tc.faa.gov</u>), the WAAS Web Application Portal allows you to view The Precision Approach (PA) Summary.

The PA Summary portion of this website allows you to:

- View all PA statistics for any dates you choose (up to 4 years in the past)
- View: position errors, LPV and LPV200, AvCon failures, missed Geo navigation messages, IGP alerts and GUS alerts, glitch events, SQM alert trips and jumps, satellite PA availability, ionospheric errors, data outages, the OEI network, PA position errors, UDREIs and the KP index

The following graphic shows you how to navigate the website. First, click on "WAAS Web Application Portal" (See red arrow below).



Once you click on "WAAS Web Application Portal", you come to the screen below. To access the PA Summary, click on "PA Summary" (See red arrow below).

Welcome to The William J. Hughes Technical Center WAAS Test Team

Interactive Web Application Portal

Disclaimer: The data on this website is for information only and should not be used for flight planning.

Real-Time Applications

OTE Display - Real-Time Receiver Data Display

SMS Display - Real-Time Service Monitoring Subsystem Display
SBAS Display (Coming Soon) - Real-Time EGNOS / MSAS / WAAS Display

Reporting Applications

Airport Actual Outages - Provides "rolled up" airport outage information on a geographic display

Airport Schedules - Shows predicted airport schedules for the next two weeks

Interactive PAN Report - Allows for interactive generation of select PAN Report Tables over a user specified period of time

NPA SPS Summary - Summary NPA SPS Statistics
PA Summary - Summary PA Statistics

Rollup Display - Displays aggregated airport and IGP statistics on a geographic display

SMS Animation Display - Animates SMS data over user selected time periods on an interactive geographic display

UDREi Daily Graphs - Displays savable UDREi GEO graphs for a given day

This is the view you see once you click on PA Summary within the WAAS Web Application Portal.


Week 1781 Day 2 : (25-FEB-2014) Week 1781 Day 1 : (24-FEB-2014) Week 1781 Day 0 : (23-FEB-2014) Week 1780 Day 6 : (22-FEB-2014) Week 1780 Day 6 : (21-FEB-2014)






Dates

Notice we can view the last 5 days (See #1 below) or we can click on the down arrow next to "Please Select Date" to pick a different date (See #2 below). These dates show the number of weeks that have elapsed since the GSP epoch date of Sunday, January 6, 1980, which was week 0. Sunday is defined as the start of a week and is always day 0; Monday is day 1; Tuesday is 2 and so on.





We are able to view the PA Summary Report as far back as Week 1564 Day 5 or January 1, 2010. This is set by the WAAS team and can be changed as needed. Please note: You must pick a date in order to populate the data fields.



Position Errors

Once you choose a date, the following screen will appear. In this case, we chose Week 1781 Day 2: (25-Feb-2014). This means it is from a Tuesday 1,781 weeks since the GPS epoch (See the red arrow below). Also, by default, we are in the Position Errors tab (See green box below). Position Errors show receiver specific errors. These are errors in with the position solution tool is in PA mode. PA mode is defined as all the corrections being processed regardless of protection level. The position solution tool is used to calculate the horizontal and vertical errors for each receiver location. National Satellite Test Bed (NSTB) and WAAS reference station receivers are included in the position errors tab. For the WAAS receivers, position errors are calculated for all three receivers at the site but only one of those receivers is shown.





As stated earlier, position errors show receiver specific errors. In the first box, we are seeing the Statistic followed by the Vertical and Horizontal Statistic. These errors are given in meters.

The Maximum Ratio row shows the largest ratio of the vertical or horizontal error to the vertical or horizontal protection level.

25-FEB-2014


Statistic	Vertical Statistic	Horizontal Statistic
95% Maximum Error	Kotzebue (NSTB) (8.5640)	Kotzebue (NSTB) (3.7660)
95% Minimum Error	Minneapolis (0.7830)	Denver (0.5430)
Maximum Error	Kotzebue (NSTB) (15.4110)	Kotzebue (NSTB) (6.7550)
Maximum Ratio	Kotzebue (NSTB) (0.4890)	Kotzebue (NSTB) (0.4170)

The second box in the Position Errors tab shows us all of the receivers including the receiver number, ID, Location, Horizontal Max (HPL), Horizontal Ratio (Horz Ratio), Vertical Max (VPL) and Vertical Ratio (Vert Ratio). The orange highlighted boxes are exceeding thresholds (See red arrow below). The receiver number (RCVR) is a number used to uniquely identify each receiver. The ID is the hex representation of the receiver number.

The Horz or Vert Max (HPL or VPL) column shows the horizontal or vertical position error and the HPL or VPL at that time in parentheses. The Horz or Vert Ratio column shows the ratio of the position error to the protection level. By default the maximum error and ratio for the day are shown. However, you can see the 95%, 99%, 99.99%, mean, or standard deviation by clicking the appropriate button.

Position 9	95%	Position 99%	Position 99.99%	sition Max	Position Mean	Position 5	Standard Deviation
RCVR	ID	City	Horz Max (HPL)	HORZ RATIO	Vert Ma (VPL)		VERT RATIO
304	0130	Atlantic City-a	2.6660 (9.6710)	0.2760 -	3.2730 (22.1	460)	0.2040 -
336	0150	Atlantic City-b	2.8930 (15.9860)	0.1910	5.8230 (33.4	180) -	0.1990
337	0151	Atlantic City-c	2.91 (15.9850)	0.1820	5.8840 (33.4	180) -	0.2050
4145	1031	Prescott	2.3590 (14.6810)	0.1630	3.7990 (25.7		0.1530
4482	1182	Bangor	1.9860 (15.85)	0.13	2.3650 (19.0		0.1240
4912	1330	Arcata	1.8550 (15.2140)	0.1260	2.1990 (39.9	870)	0.0870
5936	1730	Grand Forks	1.8710 (10.1250)	0.1850	3.50 (18.2	_	0.1920
6192	1830	Elko	1.6070 (10.6470)	0.1570	2.3330 (21		0.1090
6449	1931	Oklahoma City	1.1340 (9.2310)	0.1260	2.4680 (31.2		0.1370
6786	1A82	San Angelo	3.4180 (10.11)	0.3380	4.3370 (18.3		0.2430
11650	2D82	Kotzebue (NSTB)	6.7550 (17.1680)	0.4170 -	15.4110 (31.		0.4890
27329	6AC1	Billings	1.3410 (9.3720)	0.1430	1.7780 (17.6	-	0.11
27585	6BC1	Albuquerque	1.1770 (11.4790)	0.13	1.7970 (21.9		0.1120
27841		Anchorage	1.0130 (13.5650)	0.09	1.8410 (17.6		0.11
28097		Chicago	1.37 (9.6450)	0.1420	2.7210 (26	-	0.1190
28353	6EC1	Boston	1.5430 (14.6850)	0.1150	1.9590 (23		0.1080
28609	6FC1	Washington DC	1.3790 (10.0910)	0.1380	2.4890 (22.7	-	0.1290
28867	70C3	Denver	0.9130 (9.7150)	0.0940	1.8740 (25.8	-	0.0990
29121		Dallas	1.4450 (9.4970)	0.1520	2.0720 (19.6		0.1110
29633	73C1	Houston	1.4810 (9.3220)	0.1680	3.0120 (20.2	-	0.1580
30147		Jacksonville	1.47 (12.9330)	0.14	2.0450 (17.7		0.1250
30401		Kansas City	1.2120 (9.4610)	0.13	1.78 (26.04	-	0.0960
30658	77C2	Los Angeles	0.9830 (14.1240)	0.0830	1.7790 (25.0		0.0770
30913		Salt Lake City	1.2480 (9.7150)	0.1280	2.0960 (18.4		0.1140
31169	79C1	Miami	1.7080 (16.0420)	0.1140	2.8060 (20.2		0.1390
31425	7AC1	Memphis	1.4990 (9.6390)	0.1550	2.0380 (24		0.1140
31682		Minneapolis	1.1690 (14.8180)	0.1160	2.6140 (15.9	-	0.1640
31938	7CC2	New York	1.5210 (10.0990)	0.1530	1.8440 (18.8		0.0980
32193	7DC1	Oakland	1.9120 (13.2290)	0.1450	2.2790 (39.2	-	0.1050
	7EC1	Cleveland	1.2930 (9.7290)	0.1330	2.9270 (25.0		0.1190
32705 32963		Seattle	1.5290 (12.0940)	0.13	2.6670 (22.8		0.1540
33217		San Juan Atlanta	2.5540 (32.39)	0.0790	3.46 (37.85	-	0.0910
33473		Juneau	1.2950 (9.8910)	0.1390 0.1420	2.1420 (17.5		0.1170
33729		Cold Bay	1.6270 (11.4540) 1.3950 (20.4240)	0.0680	2.0760 (17.6 1.8120 (37.1	-	0.0670
33985		Fairbanks	1.1340 (11.4740)	0.0990	1.8370 (20.2		0.1140
34499	86C3	Kotzebue	1.1210 (12.9390)	0.0940	2.0650 (31.9		0.0920
34753	87C1	Barrow	1.3420 (13.1160)	0.1020	2.8170 (27.7		0.1180
35009	88C1	Merida	1.4430 (12.6740)	0.1140	2.71 (26.00		0.1280
35265	89C1	Mexico City	1.7820 (15.4290)	0.1160	3.3260 (46.0	_	0.1390
35521		Puerto Vallarta	1.8470 (19.5890)	0.1100	3.5170 (46.1		0.1410
35777	8BC1	Gander	1.2940 (21.9470)	0.0870	2.2060 (35.3		0.0950
36033	8CC1	Goose Bay	1.2120 (19.3920)	0.0930	3.0390 (34.0		0.0930
36289		Winnipeg	1.2120 (19.3920)	0.1310	1.7660 (19.0		0.10
36545	8EC1	Tapachula	2.5420 (36.76)	0.0690	4.4080 (38		0.13
36801	8FC1	San Jose Del Cabo	1.6270 (14.2750)	0.1140	3.5050 (38.8		0.1030
37057		Igaluit	3.9850 (38.6890)	0.1050	6.0140 (49.0		0.1260

If you click on the "View High Error/Ratio Times" box at the bottom of the screen, the data for the Times of High Errors/Ratios (GPS TOW (GMT Time)) will appear as a blue box. You can also hide this box again by clicking on the "Hide High Error/Ratio Times" box. Notice the box changes back to the "View High Error/Ratio Times" box (See arrow below).



Times of High Errors/Ratios (GPS TOW (GMT Time))									
City	Start_Time	End_Time	Error/Ratio						
Atlantic City-a	183671 (3:00:55)	186080 (3:41:04)	Ratio						
Atlantic City-a	186692 (3:51:16)	187704 (4:08:08)	Ratio						
Atlantic City-a	208219 (9:50:03)	208266 (9:50:50)	Ratio						
Atlantic City-a	215392 (11:49:36)	216667 (12:10:51)	Ratio						
Atlantic City-a	219042 (12:50:26)	219138 (12:52:02)	Ratio						
Atlantic City-a	219857 (13:04:01)	219858 (13:04:02)	Ratio						
Atlantic City-b	176526 (1:01:50)	176562 (1:02:26)	Vert						
Atlantic City-b	177191 (1:12:55)	177250 (1:13:54)	Vert						
Atlantic City-b	253008 (22:16:32)	253021 (22:16:45)	Vert						
Atlantic City-c	175480 (0:44:24)	175482 (0:44:26)	Ratio						
Atlantic City-c	177053 (1:10:37)	177528 (1:18:32)	Vert						
Atlantic City-c	253009 (22:16:33)	253021 (22:16:45)	Vert						
Kotzebue (NSTB)	173735 (0:15:19)	175020 (0:36:44)	Ratio						
Kotzebue (NSTB)	175087 (0:37:51)	179592 (1:52:56)	Vert						
Kotzebue (NSTB)	175087 (0:37:51)	179592 (1:52:56)	Ratio						
Kotzebue (NSTB)	180537 (2:08:41)	182958 (2:49:02)	Vert						
Kotzebue (NSTB)	180537 (2:08:41)	182958 (2:49:02)	Ratio						
Kotzebue (NSTB)	183947 (3:05:31)	185346 (3:28:50)	Ratio						
Kotzebue (NSTB)	187392 (4:02:56)	188408 (4:19:52)	Vert						
Kotzebue (NSTB)	190547 (4:55:31)	193195 (5:39:39)	Vert						
Kotzebue (NSTB)	200562 (7:42:26)	200692 (7:44:36)	Vert						
Kotzebue (NSTB)	200562 (7:42:26)	200692 (7:44:36)	Ratio						
Kotzebue (NSTB)	205348 (9:02:12)	211500 (10:44:44)	Ratio						
Kotzebue (NSTB)	205348 (9:02:12)	211860 (10:50:44)	Vert						
Kotzebue (NSTB)	218768 (12:45:52)	219238 (12:53:42)	Ratio						
Kotzebue (NSTB)	218768 (12:45:52)	219238 (12:53:42)	Horz						
Kotzebue (NSTB)	218768 (12:45:52)	219238 (12:53:42)	Vert						
Kotzebue (NSTB)	227852 (15:17:16)	228889 (15:34:33)	Vert						
Kotzebue (NSTB)	228947 (15:35:31)	233935 (16:58:39)	Vert						
Kotzebue (NSTB)	228947 (15:35:31)	233724 (16:55:08)	Ratio						
Kotzebue (NSTB)	237183 (17:52:47)	239144 (18:25:28)	Vert						
Kotzebue (NSTB)	237183 (17:52:47)	239144 (18:25:28)	Ratio						
Kotzebue (NSTB)	240492 (18:47:56)	242797 (19:26:21)	Ratio						
Kotzebue (NSTB)	240492 (18:47:56)	242797 (19:26:21)	Vert						
Kotzebue (NSTB)	240492 (18:47:56)	242797 (19:26:21)	Horz						
San Angelo	176051 (0:53:55)	176365 (0:59:09)	Ratio						
San Angelo	196445 (6:33:49)	197773 (6:55:57)	Ratio						
San Angelo	199628 (7:26:52)	201499 (7:58:03)	Ratio						
San Angelo	208628 (9:56:52)	209600 (10:13:04)	Horz						
San Angelo	209761 (10:15:45)	210450 (10:27:14)	Ratio						
San Angelo	209761 (10:15:45)	210261 (10:24:05)	Horz						
San Angelo San Angelo	218310 (12:38:14)	219236 (12:53:40)	Ratio						
San Angelo	218310 (12:38:14)	219236 (12:53:40)	Vert						
San Angelo	220417 (13:13:21)	220549 (13:15:33)	Ratio						
San Angelo	229063 (15:37:27)	230552 (16:02:16)	Ratio Vert						
Iqaluit Iqaluit	172963 (0:02:27)	173899 (0:18:03)							
	247606 (20:46:30)	250327 (21:31:51)	Horz						
Tapachula	176047 (0:53:51)	176597 (1:03:01)	Vert						
Tapachula	250505 (21:34:49)	251361 (21:49:05)	Vert						

Notes regarding WAAS performance for each day are located in the yellow box at the bottom of the screen. To see all of this information, you must use the scroll bar to the right of the yellow box (if it is available) or click, hold and drag the lower right corner of the box to resize (See red arrow below).

This information box is shown in each tab of the PA Summary web page.

```
Iqaluit High VPE/HPE or Ratio - All threads, no edit.

Houston, Atlantic City, G. Forks High VPE/HPE or Ratio - Selected thread only, edit required.

Atlantic City NSTB receiver (0130) reset at 1440 GMT.


Bethel Thread Switch required. 85c2 to 85c3.
```

Below is the same box after we resized it using the click, hold and drag method. Notice, the scroll bar disappeared once all the information was visible.

```
Iqaluit High VPE/HPE or Ratio - All threads, no edit.
Houston, Atlantic City, G. Forks High VPE/HPE or Ratio - Selected thread only, edit required.
Atlantic City NSTB receiver (0130) reset at 1440 GMT.
Bethel Thread Switch required, 85c2 to 85c3.
GIVE
MAAS_TIME UTC_TIME BAND IGP LAT LON FOR Date 2_25_2014 (Latitude - 15 to 30, 70 to 75 degrees) 1077380622 02/25/2014 16:23:26 3 18 20 -60 1077380718 02/25/2014 16:25:02 2 193 15 -65 1077380721 02/25/2014 16:25:05 3 18 20 -60 1077380817 02/25/2014 16:26:41 2 193 15 -65
1077404875 02/25/2014 23:07:39 2
1077404877 02/25/2014 23:07:41 3
1077404877 02/25/2014 23:07:41 3
                                                                                    -60
                                                            18
                                                                                   -60
1077404878 02/25/2014 23:07:42 3
                                                            20
                                                                        30
                                                                                    -60
 1077404880 02/25/2014 23:07:44 3
                                                                                    -55
 ***** Total Count = 95
```

LPV Coverage

Next, we will look at LPV coverage. To see the LPV coverage, click on the LPV link to view the actual map for this day (See thick, red arrow below).




When you click on LPV link, the LPV map will look similar to this map below. LPV Coverage Areas are divided into the three regions:

- Alaska outlined by the yellow line
- The Contiguous United States (CONUS) also outlined in yellow
- Canada outlined in blue


The LPV coverage for North America is divided into percentage by region. The HPL and VPL is calculated at a 1 degree grid spacing to determine if WAAS LPV service is available at each of these grid points. Adding up the availability of each grid point over a 24 hour period in a region determines the availability of WAAS LPV service in that region.

In the table within the diagram, notice the third line. This has the same information as the information in the link you clicked. WAAS LPV was available 99% of the time in 100% of the area covered in CONUS, in 97.66% of the area covered in Alaska, and in 83.28% of the area covered in Canada (See red arrow below).



The LPV Color Scale

The color scale shows the percent of WAAS LPV Coverage.



LPV 200 Coverage

To see the LPV200 coverage, click on the link to view the map for this day (See thick red arrow below).



View IGPs By Region
Must be within the last 6 weeks
View UDREIs
Max KP Index for today: 2

Coverage LPV: CONUS - 100% Alaska - 97.66% Canada - 83.28% LPV200: CONUS - 99.40% Alaska - 88.31% Canada - 64.14% Total Area Covered




When you click on LPV200 link, the map LPV200 map will look similar to this map below. LPV 200 Coverage Areas are divided into three regions:

- Alaska outlined by the yellow line
- The Contiguous United States (CONUS) also outlined in yellow
- Canada outlined in blue


The LPV 200 coverage for North America is divided into percentage by region. The HPL and VPL is calculated at a 1 degree grid spacing to determine if WAAS LPV 200 service is available at each of these grid points. Adding up the availability of each grid point over a 24 hour period in a region determines the availability of WAAS LPV 200 service in that region.

In the table within the diagram, notice the third line. This has the same information as the information in the link you clicked. WAAS LPV was available 99% of the time in 99.40% of the area covered in CONUS, in 88.31% of the area covered in Alaska and in 64.14% of the area covered in Canada (See red arrow below).



The LPV200 Color Scale

The color scale shows the percent of WAAS LPV200 Coverage.



Total Area Covered

To see the Total Area Covered over a few days, click on Total Area Covered (See thick, red arrow below).




View IGPs By Region
Must be within the last 6 weeks
View UDREIs
Max KP Index for today: 2

Coverage LPV: CONUS - 100% Alaska - 97.66% Canada - 83.28% LPV200: CONUS - 99.40% Alaska - 88.31% Canada - 64.14% Total Area Covered



Total Area Covered shows the Total Area covered for LPV and LPV 200. The total area covered is shown in square kilometers and includes the CONUS, Alaska, and Canada regions. The blue line indicates the number of square kilometers covered with 99% availability and the yellow line shows the number of square kilometers covered with 100% availability.




Alert Explorer


Click on View Alert Explorer for Current Day (See red arrow below).




Once you click on View Alert Explorer for Current Day, you will see a screen similar to this one:



Here Alert Explorer is showing us default dates, which you can change using the calendars to either side of the Start and End Time (See #1 below). The Alert types are highlighted below (See #2 below). By default, all boxes are checked initially. To uncheck one or more, simply uncheck them and re-click the green "View Alerts Between Dates" Box. You can also zoom in closer within the Gantt chart (See #3 below). Simply left-click your mouse and drag and draw a box around the area you would like a closer look at and release. To go back to the original view, double-click anywhere inside the chart.




Here is the Alert Explorer using different dates. We are looking at 2/24/14 00:00 to 2/28/14 00:00. Both #1 and #2 below show the dates selected. #3 is showing us that there was more maintenance and more faults over this expanded period of time.



If you click on slide calendars up, you will see more of the Gantt graph.




After sliding the calendars up, the chart is more readable. (See below) To view the calendars once again, click on "slide Calendars down" (See red arrow below).




To view the same information in a table, click on "Tabular View" (See thick red arrow below). The table shows the Alerts including: the Start time of the alert, End time, Type, Start Time (in absolute time of week), Duration, Short Name (site abbreviation), Site Name, Host Name (a code for each WAAS reference station receiver), Prev Mode, Alert Mode and End Mode.






Clicking on any of the blue highlighted words in the table will open a box that further describes the fault details (See red arrow below).

To close this dialog box and return to Alert Explorer, click on the "x" in the top right corner of the box (See small red box).



Clicking on "Create Shareable Link" will bring up this screen. From here you can save and share the link to this particular page. To close this dialog box and return to Alert Explorer, click on the "x" in the top right corner of the box (See small red box below).





Here is a portion of the screen you would see if you clicked on "View Begin State." The top box shows the GUS, or Geostationary Uplink Station information. Notice the table lists the mode, short name and long name for the GUS. The "Begin State" for each entry in the table is that site's state at the beginning of the time period chosen. Also, the last time the state was changed for a particular site is shown in the second column of the table.



					GEO Ir	nform	ation										
GEO ¢	LAST TIME OF CHANGED		GU	S MODE •	GUS SHORT NAME	۰	GUS LONG NAME •	C&V S	V SHORT NAME •		&V SITE NAME •						
133	2/7/1	4 08:00:37 GMT	PI	RIMARY	SZP		Santa_Paula		ZTL		Atlanta						
133	2/7/1	4 08:00:35 GMT	В	ACKUP	HDH		Paumalu		ZTL		Atlanta						
135	11/19/	13 00:41:36 GMT	PI	RIMARY	APC		Napa		ZLA		Los Angeles						
135	2/19/1	14 19:17:44 GMT	В	ACKUP	APA		Littleton		ZLA		Los Angeles						
138	2/16/1	14 00:42:33 GMT	PI	RIMARY	QWE		Woodbine		ZDC	V	Vashington, DC						
138	2/16/1	14 01:38:06 GMT	В	ACKUP	BRE-B		Brewster-B		ZDC	V	Vashington, DC						
				No	ode State Infor	matio	n (128 Nodes)										
SHORT	NAME +	LAST TIME CHANGED	0	NODE MODE *	NODE TYPE *		LONG NAME	۰	SITE NAME	Φ	HOST NAME +						
APA	Α	2/19/14 19:17:44 G	MT	BACKUP	GUS		Littleton		Littleton		wltngusp1c1						
APO	c [11/19/13 00:41:36 G	MT	PRIMARY	GUS	Napa		Napa			wapcgusp1c1						
BET	.Α	11/12/13 21:15:48 G	MT	NORMAL	WRE		Bethel-A		Bethel		wbetwrsp1c1						
BET	.В	2/24/14 22:08:46 G	MT	OFFLINE	WRE		Bethel-B		Bethel		wbetwrsp2c1						
BET	.c	2/24/14 20:14:44 G	GMT NORMAL		WRE		Bethel-C		Bethel		wbetwrsp3c1						
BIL-	A	1/29/14 22:10:12 G	MT	NORMAL	WRE		Billings-A		Billings-A Billings		Billings		wbilwrsp1c1				
BIL-	В	2/11/14 21:36:34 G	MT	NORMAL	WRE	Billings-B		Billings-B Billings			wbilwrsp2c1						
BIL-	С	1/29/14 22:10:59 G	MT	NORMAL	WRE		Billings-C		Billings		wbilwrsp3c1						
BRE	.В	2/16/14 01:38:06 G	MT	BACKUP	GUS		Brewster-B		Brewster		wbregusp2c1						
BRW	-Α	2/6/14 03:19:53 GN	ΛT	NORMAL	WRE		Barrow-A		Barrow-A Ba		Barrow-A		Barrow-A Barrow		Barrow		wbrwwrsp1c1
BRW-B		2/5/14 23:14:55 GN	ΛT	NORMAL	WRE	Barrow-B		Barrow			wbrwwrsp2c1						
BRW	.C	2/20/14 20:09:12 G	MT	T NORMAL WRE Barrow-C		Barrow-C		Barrow		wbrwwrsp3c1							
CDB	-Α	1/7/14 05:50:30 GMT NORMAL WRE Cold_Bay-A		Cold_Bay-A		Cold Bay		wcdbwrsp1c1									
CDB	-B	1/7/14 05:50:30 GN	ΛT	NORMAL	WRE		Cold_Bay-B		Cold Bay		wcdbwrsp2c1						
CDB	.c	1/7/14 05:50:30 GI	ΛT	NORMAL	WRE		Cold Bay-C		Cold Bay		wcdbwrsp3c1						

Here is a portion of the screen you would see if you clicked on "View End State." We are viewing the System Status at the end of our chosen dates.



					GEO	Inform	ation					
		LAST TIME										
GEO ◆		CHANGED	GU	IS MODE •	GUS SHORT NAME	. •	GUS LONG NAME •	C&V	SHORT NAME •	C	&V SITE NAME	
133	2/7/1	4 08:00:37 GMT	P	RIMARY	SZP		Santa_Paula		ZTL		Atlanta	
133	2/7/1	4 08:00:35 GMT	В	ACKUP	HDH		Paumalu		ZTL		Atlanta	
135 1	1/19/	13 00:41:36 GMT	P	RIMARY	APC		Napa		ZLA		Los Angeles	
135	2/19/	14 19:17:44 GMT	В	ACKUP	APA		Littleton		ZLA		Los Angeles	
138	2/16/	14 00:42:33 GMT	P	RIMARY	QWE		Woodbine		ZDC		Washington, DC	
138	2/16/	14 01:38:06 GMT	В	ACKUP	BRE-B		Brewster-B ZD		ZDC		Vashington, DC	
					Node State Info	rmatic	n (128 Nodes)					
					Trodo otato imo		11 (120 110000)					
SHORT NAME	۰	LAST TIME CHANGED	•	NODE MODE	NODE TYPE •		LONG NAME	•	SITE NAME	•	HOST NAME	
APA		2/19/14 19:17:44 GI	MT	BACKUP	GUS		Littleton		Littleton		wltngusp1c1	
APC		11/19/13 00:41:36 G	MT	PRIMARY	GUS		Napa Napa			wapcgusp1c		
BET-A		2/25/14 21:14:56 GN	MT	OFFLINE	WRE		Bethel-A Bethel		Bethel		wbetwrsp1c	
BET-B		2/25/14 19:36:02 GN	MT	NORMAL	WRE		Bethel-B		Bethel		wbetwrsp2c	
BET-C		2/24/14 20:14:44 GI	MT	NORMAL	WRE	WRE Bethel-C		Bethel-C Bethel			wbetwrsp3c	
BIL-A		1/29/14 22:10:12 GM	MT	NORMAL	WRE		Billings-A		Billings		wbilwrsp1c1	
BIL-B		2/11/14 21:36:34 GN	MT	NORMAL	WRE		Billings-B		Billings		wbilwrsp2c1	
BIL-C		1/29/14 22:10:59 GN	MT	NORMAL	WRE	Billings-C		s-C Billings			wbilwrsp3c1	
BRE-B		2/16/14 01:38:06 GM	MT	BACKUP	GUS	Brewster-B		Brewster		wbregusp2c		
BRW-A		2/6/14 03:19:53 GM	AT	NORMAL	WRE		Barrow-A		Barrow		wbrwwrsp1c	
BRW-B		2/5/14 23:14:55 GM	AT	NORMAL	WRE		Barrow-B		Barrow		wbrwwrsp2c	
	—				WRE		Barrow-C				wbrwwrsp3c	

AVCON

Here we are looking at data for Week 1781 Day 6, or March 1, 2014 (See #1 below).

We clicked the Availability Continuity, or "AVCON", tab (See #2 below). AvCon is receiver availability taking into account the continuity of actual outages. This page shows tables for both LPV AvCon and LPV200 AvCon.

LPV must have a VPL <50 meters and the HPL <40 meters, while LPV200 must have the VPL <35 meters and the HPL <40 meters horizontal.

The boxes are highlighted in orange if the receiver does not meet its thresholds. If it exceeds the number of outages or drops below the expected AvCon, it will be highlighted. For example, in LPV AvCon (See #3 below), the Mauna Loa receiver's b-thread is highlighted due to the receiver exceeding the number of outages 3:2. San Juan did not exceed the number of outages at 5:8, but it did drop below the expected AvCon of 0.1191.

These thresholds are computed every 30 days to reflect dynamic variables for each receiver, such as GPS constellation changes or changes to the WAAS. When analyzing data for a particular day, the receiver will be compared to the threshold for the time period of the selected day only.

#4 shows the same data with regards to LPV200. The blue box beneath #4 shows the LPV200 data in GMT Time of Week (GPS TOW) and GMT Time in parenthesis, along with the outage duration in seconds.

The blue box (#5 below) shows both the start time and end time of LPV AvCon Failures in GMT Time of Week (GPS TOW) and GMT Time in parenthesis, along with the outage duration in seconds.

View IGPs By Region
Must be within the last 6 weeks
View UDREIs
Max KP Index for today: 3

Coverage LPV: CONUS - 100% Alaska - 97.34% Canada - 81.07% LPV200: CONUS - 99.90% Alaska - 79.38% Canada - 61.07% Total Area Covered

Г	View Alert Explorer	for Current Day	7								
ľ	Position E	2 AVCON	Geo Nav Messag Data Outag		Alerts SV/T6					je Errors	Iono Errors
1		LPV A	NvCon		Δ	7		LPV200 A	vCon		
	City		es Threshold AvCon		'	City		Outages :			n: AvCon
Т	Kotzebue (NSTB	-		959 : 0.9656		Arcata		Thres 1:			reshold 2:0.9677
1	Mauna Loa-a	2:		0:0		Bango	_	4:			1:0.9402
	Mauna Loa-b	3:		0:0	_	Elko		1:			0:0.9840
	Barrow	1:		982:0.9510	K	otzebue (_	6:			1:0.9111
	Gander	1:		974: 0.9537	-	Mauna Lo		2:			0:0
	Honolulu	2:		0:0		Mauna Lo	_	3:			0:0
	Iqaluit Marriag City	3:		027: 0.8519		Barroy	_	3:			0:0.8883
	Mexico City	1:		974:0.9890		Cold B	ay	6:	6		2:0.9066
	Puerto Vallarta San Juan	2:		816: 0.9672 925: 0.1191		Gande		6:	8		7:0.7553
	Tapachula	2:		174: 0.0131		Goose E	Bay	2:	1	0.9737	7:0.9137
L	тараснина	Zi	3 0.0	174 : 0.0131		Honolu	lu	2:	2	(0:0
7	Times of AvCon	Failuree/GDS T	OW (GMT Time)			Iqalui	it	12	9	0.6004	1:0.6341
ı	City	Start Time	End Time	Outage Time		Kotzeb	ue	2:	1	0.9669	9:0.9514
₽.	Kotzebue	546882	547087			Merida	a	2:	2	0.9900	5:0.9734
	(NSTB)	(7:54:26)	(7:57:51)	206		Mexico (7:	7	0.8810	0:0.8698
	Mauna Loa-a	518400	597600	79201		Oaklan	_	1:			0:0.9778
	Madria Loa a	(23:59:44)	(21:59:44)	79201		Puerto Va		9:	8	0.8503	3:0.8503
	Mauna Loa-a	600874 (22:54:18)	604799 (23:59:43)	3926		San Jose Cabo		7:			0:0.8980
	Mauna Loa-b	518400 (23:59:44)	539929 (5:58:33)	21530		San Jua Tapach		2:			034 : 0 1 : 0.0067
	Mauna Loa-b	540843 (6:13:47)	597600 (21:59:44)	56758		ity	Sta	rt Time	End Ti	me 0	utage Time
	Mauna Loa-b	600874 (22:54:18)	604799 (23:59:43)	3926	Ar	cata ngor	584261	(18:17:25) 2 (0:54:56)	585041 (18	:30:25)	781 1309
	Barrow	563058 (12:24:02)	563059 (12:24:03)	2	Ba	ngor ngor	575065	(15:44:09) (20:44:39)	575065 (15	:44:09)	1
	Gander	598664 (22:17:28)	598736 (22:18:40)	73	Ba	ngor Iko	598320	(22:11:44)	598525 (22	:15:09)	206 20
	Honolulu	518400 (23:59:44)	597600 (21:59:44)	79201		ie (NSTB)		7 (3:49:31)			399


This is a screen shot and continuation from the screen show above. Below, the red box highlights the LP AvCon along with outages and AvCon numbers. The blue boxes below this show the start and end time of all outages along with the outage duration for all affected receivers. LP must have the HPL < 40 meters. There is no vertical component to LP.

Tapachula	575601 (15:53:05)	604799 (23:59:43)	29199	
	LPA	vCon		
City	Outag	Outages AvCo		
Mauna Loa	-a 2		0	
Mauna Loa	-b 3		0	
Honolulu	2		0	
Iqaluit	2		0.9894	
Mexico Cit	y 1		0.9974	
San Juan	13		0.3862	
Tapachula	2		0.0174	
City	Start Time	End Time	Outage Time	
Mauna Loa-	518400	597600	79201	
a	(23:59:44)	(21:59:44)	79201	
Mauna Loa-	600874	604799	3926	
a	(22:54:18)	(23:59:43)		
Mauna Loa- b	518400	539929	21530	
Mauna Loa-	(23:59:44) 540843	(5:58:33) 597600		
b Maulia Lua-	(6:13:47)	(21:59:44)	56758	
Mauna Loa-	600874	604799		
b	(22:54:18)	(23:59:43)	3926	
Honolulu	518400	597600	79201	
Honoiulu	(23:59:44)	(21:59:44)	79201	
Honolulu	600874	604799	3926	
Hollolala	(22:54:18)	(23:59:43)	3320	
Iqaluit	592915	593477	563	
	(20:41:39)	(20:51:01)		
Iqaluit	595426 (21:23:30)	595481 (21:24:25)	56	
	598089	598159		
Mexico City	(22:07:53)	(22:09:03)	71	
Can Just	518400	525683	7204	
San Juan	(23:59:44)	(2:01:07)	7284	

Goose Bay	601394 (23:02:58)	601406 (23:03:10)	13
Honolulu	518400 (23:59:44)	597600 (21:59:44)	79201
Honolulu	600874 (22:54:18)	604799 (23:59:43)	3926
Iqaluit	518400 (23:59:44)	519068 (0:10:52)	669
Iqaluit	520085 (0:27:49)	524867 (1:47:31)	4783
Iqaluit	527503 (2:31:27)	527778 (2:36:02)	276
Iqaluit	535841 (4:50:25)	536045 (4:53:49)	205
Iqaluit	539462 (5:50:46)	540365 (6:05:49)	904
Iqaluit	541615 (6:26:39)	542190 (6:36:14)	576
Iqaluit	544908 (7:21:32)	545699 (7:34:43)	792
Iqaluit	548239 (8:17:03)	552270 (9:24:14)	4032
Iqaluit	557532 (10:51:56)	559250 (11:20:34)	1719
Iqaluit	564401 (12:46:25)	564737 (12:52:01)	337
Iqaluit	581682 (17:34:26)	581943 (17:38:47)	262
Iqaluit	586551 (18:55:35)	604722 (23:58:26)	18172
Kotzebue	536738 (5:05:22)	537098 (5:11:22)	361
Kotzebue	552793 (9:32:57)	554989 (10:09:33)	2197
Merida	583399 (18:03:03)	583413 (18:03:17)	15
Merida	597222 (21:53:26)	597714 (22:01:38)	493
Mexico City	548340 (8:18:44)	550784 (8:59:28)	2445
Mexico City	556985 (10:42:49)	557708 (10:54:52)	724
Mexico City	560162 (11:35:46)	561595 (11:59:39)	1434
Mexico City	568543 (13:55:27)	569079 (14:04:23)	537
Mexico City	571188 (14:39:32)	571642 (14:47:06)	455
Mexico City	596723 (21:45:07)	599307 (22:28:11)	2585
Mexico City	602670 (23:24:14)	603720 (23:41:44)	1051
Oakland	584945 (18:28:49)	585051 (18:30:35)	107
Puerto Vallarta	527677 (2:34:21)	527965 (2:39:09)	289
Puerto Vallarta	542515 (6:41:39)	544356 (7:12:20)	1842
Puerto Vallarta	550236 (8:50:20)	550511 (8:54:55)	276
Puerto Vallarta	555877 (10:24:21)	557678 (10:54:22)	1802
Puerto Vallarta	560378 (11:39:22)	561564 (11:59:08)	1187
Puerto Vallarta	566462 (13:20:46)	568910 (14:01:34)	2449
Puerto Vallarta	570799 (14:33:03)	570809 (14:33:13)	11
Puerto Vallarta	596334 (21:38:38)	599097 (22:24:41)	2764
Puerto Vallarta	601734 (23:08:38)	602696 (23:24:40)	963
San Jose Del Cabo	527071 (2-20-15)	520012 (2-20-57)	42

Geo Nav Messages

Here we are looking at January 17, 2014 (See #1 below). We clicked on the "Geo Nav Messages" tab (See #2 below). The table is a list of any missed messages from Geostationary satellites 133, 135 and 138. We receive messages from these receivers every second. The Time Out and Time In is given in GPS Time of Week (GPS TOW) and GMT Time in parenthesis. The number of missed seconds, number of transmitted message type 0's, the time back to PA Mode, seconds not in PA mode and a description is given for each missed message. PA Mode refers to a state in which a user would be able to conduct a Precision Approach. Note: Usually when 4 or 5 seconds are missed, it is due to a manual switchover. A number over 10 seconds normally means the GUS, or uplink station, faulted.




SubSystem Alerts

The date for this information is located beneath "PA Summary Report". Here we are looking at January 17, 2014 (See #1 below).

The SubSystem Alert tab is open (#2 below). This tab shows the same information as Alert Explorer. The GUS Alerts listed in the table show the Geostationary satellite number(s) and name; the time of week the alert started and ended along with the duration in seconds (#3 below).

A description of the alerts is also included:

- IGP alerts refer to when certain IGPs go to 45 meters. The IGPs chosen are those in the CONUS and Alaska regions.
- Selected Source alerts refer to when the C&V selected source of a GUS is changed.
- CnV alerts refer to when one of the C&Vs changes mode.
- IGP, Selected Source, and CnV alerts are rare.




SV/T6 Alerts

The SV Alerts tab is open (#2 below) to February 23, 2014 (See #1 below). Originating from Geostationary satellites, SV alerts inform us when a satellite's User Differential Range Error (UDREI) is changing and WAAS transmits at least 4 consecutive messages to ensure a user received the alert. The Geostationary satellites 133, 135 and 138 are listed separately in the tables below (See #3 below).


The columns include: the PRN number that shows which satellite the alert refers to; the time in GPS Time of Week (GPS TOW) and GMT Time in parenthesis; the number of seconds it took to get back into PA mode; the number of seconds not in PA mode; the UDREI change (previous-current); the message type and # of messages received in a row; the time the UDREi for the noted satellite was last in PA mode in GPS TOW, and the severity of the glitch. Glitches are defined in the Glitch Events tab.

In the UDREI column, if the number is 12 or 13, the satellite is in NPA mode only. If the UDREi is >13, satellite is in the Not Monitored or Do Not Use (DNU) state. A number <12 indicates a satellite is in PA mode.




Glitch Events

The "Glitch Events" tab, open (#2 below) to March 23, 2014 (See #1 below), shows us specific satellites that exhibit abnormal operation, from the point of view of the WAAS reference station receivers. Below, both Satellite 4 and 2 had glitches. The Glitch Severity key indicates which events caused the glitch. Glitch Severity ranges from 0-3, with 0 showing receiver tracking was limited due to > 14 satellites visible and 3 indicating more than just SQM was affected and all receivers lost track of a satellite. The reference to SQM is for a receiver that is not outputting SQM data but is outputting L1 and L2 data. The Glitch Stat Failure column shows the number of receivers that are not providing L1, L2, or SQM data out of how many receivers should be transmitting this data. To see the information in a graph, click on the light orange "View Glitch Chart" box.




When we click on the "View Glitch Chart" button, the default dates are for one month prior to the date we are viewing. We can change these dates (See red arrow below). The newly input dates must be in the format indicated.



Below is the screen once we click on the green "Go" button. Here we have a graph of the varying magnitude of glitches that occurred. Glitches are degradations in the signal that can cause WAAS receivers to lose track of the GPS signal. The dots indicate the severity of the glitch events. As the key code says on the top of the chart:

- Severity 1 = Green dots that indicate that a significant number of receivers- but not all receivers- lost track of the satellite.
- Severity 2 = Blue dots indicate that *only* Signal Quality Monitoring (SQM) was affected and all receivers lost track.
- Severity 3 =Red dots indicate more than just SQM was affected and all receivers lost track.



View Glitch Event Details

When clicking on the "View Glitch Event Details" box, a new table shows the satellite, its type, the start and end time, along with the duration in seconds. Here is an example from March 23, 1014.


View Glitch Event Details

SAT	STAT_TYPE	START_T	END_T	LENGTH
4	SQM	12026	12035	9
4	L2	12027	12035	8
4	L1	12027	12063	36
4	L2	12044	12052	8
4	SQM	12044	12052	8
4	SQM	12092	12100	8
4	L1	12093	12111	18
4	L2	12093	12100	7
4	SQM	12182	12190	8
4	L2	12183	12190	7
4	L1	12183	12201	18
4	SQM	12248	12257	9
4	L1	12249	12267	18
4	L2	12249	12256	7


SQM Data

The next tab is the Signal Quality Monitoring (SQM) data tab (See red arrow below). SQM Alerts show any anomalies in the GPS satellite signal. An SQM Alert Trip shows any trips of the reported by the Technical Center SQM tool. This rarely happens. A SQM Alert Jump shows when SQM increases but it is not necessarily a trip (See #1 below).

Daily Max Trip Ratio shows the max ratio per satellite over a 24 hour period. PRN Bias Daily Average Trend shows the four-month trend (#2 below). Both of those links show data from the Technical Center SQM tool, not the operational WAAS.




In SQM Alerts, when we press on *Daily Max Trip Ratio (PRN Bias/Threshold Ratio Plot)*, we see the max ratio per satellite over a 24 hour period. PRN Bias is the overall estimated deformation per satellite across receivers. The Max Trip Ratio combines information from the satellite together and computes a threshold. The Ratio of PRN Bias ÷ the threshold should be <1. Below are the four detection matrix (DM) graphs that determine the SQM in all 4 metrics.



In SQM Alerts, when we press on *PRN Bias Daily Average Trend*, a PDF of PRN Bias opens showing a 4 month trend per satellite. While the diagrams below depict only information from PRN 1 and PRN 2, in actuality the pdf shows info for all 32 satellites in the WAAS system. The X axis indicates the date while the Y axis shows the daily average of the PRN Bias.

The 4 different Detection Matrices (DM) are shown using different colors:

- Red= DM1
- Green = DM2
- Blue = DM3
- Black = DM4




Range Errors

The Range Error tab (#1 below) shows satellite unboundings (See #2 below). These are specific per satellite per receiver. Range Errors include: clock, trophospheric or ionospheric errors. Unboundings occur when the UDRE does not bound the satellite range error.


#3 shows the Satellite PA availability. The percentage availability in the first column is based on the expected UDREi of the satellite.

#4 shows NPA availability of GEO 133. This GEO is never in PA mode so its UDREi never gets below 12. This shows the percent of the day that it was an NPA quality ranging GEO. UDREI_12_AVAIL shows the percent of the day it was in a UDREI of 12.


#5 shows the max range error for each satellite per receiver per satellite. The highlighted box shows the maximum range error for each receiver.



At the bottom of the Range Error tab, you can push the "Push to See Range Trends" button (See red arrow below) to open graphs similar to the one below. This is a screen shot of a portion of the page. Here we can see the Washington D.C. range errors (in meters) for satellites 1- 14. In actuality, the webpage will show satellites 1-32 along with Geostationary satellites, all indicated by their own colored line in the graphs.








Iono Errors


This is the ionospheric portion of the range error. The satellites are listed in the first column. The other columns are the ionospheric errors in meters for the noted receivers. The highest ionospheric error of each receiver is highlighted.



Data Outages

The Data Outages tab shows us the number of seconds we did not receive data for a particular receiver. The top box shows the outage totals while the bottom box shows the times for each outage. Only outages >3 seconds are recorded in the bottom box. The bottom box also shows the Time Out and Time In in GPS Time of Week (GPS TOW) and GMT Time in parenthesis. Arcata in the bottom box is showing 86,400 seconds of continuous outage, which equals the entire day.

Please note: For the WAAS sites, one string from each WAAS reference station is chosen and shown in this tab. The NSTB sites have only one string unless noted with a suffix of –a, -b, etc.




OEI Network

The diagram below shows a portion of the Operational External Interface (OEI) Network Screen. These show outages from receivers for *ALL* threads. The OEI server obtains identical information from 2 rings of data for each receiver:

- NET_RING1 shows how many seconds were missing on the Ring 1 network.
- NET_RING2 shows how many seconds were missing on Ring 2 network.
- NET_MISSING is a merged file showing seconds that were missing from both Ring 1 and Ring 2 at the same time.
- DC_MISSING is the number of seconds that data is missing for data collection. Both NET_MISSING and DC_MISSING should match.

The orange highlights anything that is missing data from that particular receiver or if the last 2 columns do not match.




wmmxwrsp1

PRN138 L1SNR


Here is a partial screen shot of PRN138 L1 Signal to Noise Ratio (L1SNR) in decibels, as reported by the WAAS receiver (See #1 below). This page is meant to determine if the signal power received at various reference stations from the WAAS GEO 138 differs from a normal level. A significant difference could be an indication of Radio Frequency Interference (RFI). The table lists receivers in the first column followed by the receiver's location, the signal to noise average, minimum and maximum columns.

The box labeled #2 is normally at the bottom of the PRN138 L1SNR screen. This box shows the drop in L1SNR. If the signal to noise drops >6 decibels, the signal was possibly interrupted by RFI. The orange highlighted boxes show the minimum L1SNR >9db subtracted from the average *or* the length of time exceeded 300 seconds. Note that when there is a GUS switchover for PRN 138 all the receivers that track that GEO will be listed in box #2. GUS switchovers are listed in the Alert Explorer.



PA Position Errors

Unlike the Position Error tab which shows position errors when LPV service is available, the PA Position Errors tab shows the position errors when the receivers are out of LPV service. The table below shows Position errors when the HPL is > 40 meters and/or the VPL is > 50 meters. Errors are listed when the tool is in PA mode. Also, the 95%, 99%, 99.99%, maximum, mean, and standard deviation can be displayed by choosing the appropriate button.



Edits

These edits are entered manually when a receiver malfunctions. Below, the edit ID, start and stop time of week and comments are listed in the table, followed by the flag. You can view automatic edits by pressing the orange "View Automatic Edits" button at the bottom of the screen. Thresholds have been established in the evaluation software to determine when automatic editing (i.e. removal) of data should occur. The purpose of this website is to measure the performance of WAAS. When one of the tools (i.e. receivers) that is used to measure performance malfunctions the date from that tool is removed from the results.


In the Flag column, a 0 means the edit was not done and 1 means the edit was completed. Any edits that are not done (i.e. have a flag of 0) will be done at a later time.



When you click on the "View Automatic Edits" button, you can view all the edits. Below is a partial table from the website.

Listed in this table are: the receiver, time of week (TOW), Nav mode, number of satellites that were valid, the HPL, VPL, Flag and Geostationary satellite number.

Here the number listed under Flag shows us how many satellites discarded from the solution. If VPL is > 50 or HPL is > 40, the data is automatically edited out of the statistics.



View UDREIs

To view UDREIs for this day, click on "View URDEIs" in the top right corner of the PA Summary (See red arrow).

Week 1783 Day 1 : (10-MAR-2014) Week 1783 Day 0 : (9-MAR-2014) Week 1782 Day 6 : (8-MAR-2014) Week 1782 Day 5 : (7-MAR-2014) Week 1782 Day 4 : (6-MAR-2014)





The User Differential Range Errors (UDREis) are shown per satellite per hour for a 24 hour period. The image below depicts only two satellites, PRN 1 and PRN 2. In actuality, satellites 1-32 along with all Geostationary satellites 133, 135 and 138 are shown. Notice the date is shown and default Geostationary satellite Geo 138 is checked. The GEO means that the UDREi corrections are shown for that GEO. The green line indicates the expected UDREIs and the red shows the actual UDREi's. Note too that the lowest UDREi shown is 7, even though the UDREi can get lower.

The UDREi transmitted from different GEO satellites can be viewed by checking the box next to the GEO PRN number. Also, different dates can be entered to look at the UDREi charts for different days. The entered date must be in the DD-MM-YYYY format. A calendar does pop up when the Enter Date box is clicked.



View IGPs By Region and Max KP Index

Both Ionospheric Grid Point Status (IGPs) and the K-index (Kp) relate to ionospheric effects on the GPS signals. The Kp Index is a calculation based on disturbances in the earth's magnetic field with regards to a geomagnetic storm with a range of 0-9. 1 is calm while 5 or more indicates high ionospheric activity. In this example the Kp index is at 4. To select a Kp plot, click on "Max KP Index for today: 4" (See red arrow below).

Week 1783 Dav 1 : (10-MAR-2014) Week 1783 Dav 0 : (9-MAR-2014) Week 1782 Dav 6 : (8-MAR-2014) Week 1782 Dav 5 : (7-MAR-2014) Week 1782 Dav 4 : (6-MAR-2014)





Next, select the year, plots, Kp file and appropriate gif file. In the example below, we chose "2014, "2014_plots," "Kp," and "20140717." The table for 07/17/2014 is displayed.

Please note: we can only go as far back as 1996 for Kp Index files.

